


# MEA 500/10 i. r., 500/30 i. r.

## Electrode layout



The letter of the electrode number code refers to the row number, and the digit is the column number. The specified MEA1060 amplifier pin numbers are the MEA System channel numbers that are used in the MC\_Rack program. The substrate-integrated reference electrode (i. r.) is connected to pin 15 of the MEA1060 amplifier.