HighDenseMEA

multichannel systems

Electrode layout



The first letter of the electrode number code refers to the row number, the digit is the column number, and the second letter refers to the electrode field (left or right) of the HighDenseMEA. The specified MEA1060 pin numbers are the MEA System channel numbers that are used in the MC_Rack program.

© 2005 Multi Channel Systems MCS GmbH